

NOTE: USE A 1/16" Balsa Sheeting Strip Under the L.E. to act as JIG when building the stabilizer

REMOVE FOR END NEAR PAPER TUBE

3/32" LITE PLYWOOD BRACKETS FOR SERVO SUPPORT RAILS, MAKE 4

3/32" Balsa Sheeting

1/4" Balsa Sheet

1/8" Balsa SUB L.E.

1/4" Balsa Sheet Leading Edge - NOTE TAPER

NOTE: WING RIBS W-2 THRU W-13 ARE 3/32" Balsa Sheet

STABILIZER

ELEVATOR

LEFT WING PANEL

RIGHT WING PANEL - TOP VIEW



ARIES XJW-120

DESIGNED & DRAWN BY JOHN T. WHITE FILED PLAN BY JOE DEMARCO

SHEET 2 OF 2

PLAN NO. 125912